

FOTECHEM Liquid Light 2154

An entirely new chemical concept to complet the light exposure reaction on all FOTECO emulsions



Wash-out as usual until the image area appears open, then **stop** washing.



Now apply immediately FOTECHEM 2154 with a soft sponge, starting from the squeegee side. Let stand to react for maximum 30 seconds.



Then rinse both sides with plenty of water; the emulsion has hardened and does no longer wash away. This prevents scumming.



Dry stencil and make ready as usual.

This is not a chemical hardener (catalyst) but increases stencil durability of under-exposed emulsions.

May 2004