



Fotec AG

Phone:
e-mail:

Eigenheimstr. 22 CH-8700 Küsnacht
P.O.Box 1123 Switzerland
+41 44 913 30 00 Fax: +41 44 910 45 25
info@fotec.ch www.fotec.ch

TECHNICAL INFORMATION

Küsnacht, June 1999

FOTECHEM 2200 A + B

Pulver Entwickler

Powder developer

Für indirekte Gelatine Fotokontakt-Filme

For indirect gelatin foto stencil films

A+B Pulver zusammen ergeben

A+B powder together make

4 Liter Entwickler

4 liters developer

1. Wasser bereit stellen.
2. Wassertemperatur zwischen 18 und 24°C halten.
3. A Pulver zuerst begeben und gut umrühren.
4. Dann B Pulver eingeben.
5. Gut umrühren bis beide Pulver ganz aufgelöst sind.
6. Entwickler in Schale giessen.
7. Film gleichmässig ins Bad einziehen;
FOTECFILM während ca. 90 Sekunden unter gedämpftem Licht entwickeln.
8. Entwicklerbad abdecken, wenn nicht im Gebrauch.
9. Entwickler **nie** in geschlossene Behälter zurückgiessen.
10. Entwickler nach mehrmaligem Gebrauch oder nach 2-3 Tagen ersetzen.

1. *Fill container with water.*
2. *Keep water temperature between 18 and 24°C.*
3. *Start with powder A , and stir well.*
4. *Add powder B.*
5. *Stir well until both powders are dissolved.*
6. *Pour developer into tray.*
7. *Insert FOTECFILM evenly and develop for 90 sec. under subdued light conditions.*
8. *Cover developer bath after each use.*
9. *Do **not** bottle.*
10. *Discard developer after 2-3 days, or after intensive use.*

FOTEC AG